

ANNEXE N° 1

Balises de positionnement Pornichet Select 6.50 2019

1. Des balises de positionnement Yellow Brick seront installées sur les bateaux.
2. Ces balises seront installées dans le but de :
 - Augmenter la sécurité de la course en permettant à la direction de course de connaître la position des concurrents.
 - Améliorer la communication de la course et des concurrents en offrant une publication de classement et cartographie.
3. Installation de la balise :
 - La balise devra être fixée au balcon arrière (Extérieur panneaux solaires).
 - **Position** : à l'arrière du bateau dégagée des panneaux
 - **Fixation** : par élastique et scratch



Sending a 'one-off' position report (manual position report):

To send a one-off position report, press and hold the UP ▲ key for 5 seconds. The screen will wake up and a countdown will be displayed to confirm that the position is being sent.

To send an alert message:

Lift the flap at the bottom of the tracker, and hold down the red alert button for 5 seconds ②. The screen will say 'Sending Alert...' - ensure that the unit has the best view of the sky possible and leave until the green LED stops flashing. You can repeat this process.

To charge:

If you need to charge the tracker, simply unscrew the cap covering the USB port on the bottom of the unit ③ and plug into the USB charger. A red LED will turn on when the unit is charging. After charging, check that the USB cap is done back up again very tightly to ensure the unit remains fully waterproof.

① Keypad: UP, DOWN, LEFT, RIGHT and OK

② ALERT Key ③ On rear, USB Port